



# A & F WOOD PRODUCTS, INC.

5665 Sterling Drive Howell, MI 48843

Phone: 517.545.5811 Fax: 517.545.5633 Toll Free: 800.367.3293

www.afwood.com

## Extention Kit #1752 & #1753 Instructions Built-Up Pocket Door Frame Fits all Built-Up Pocket Door Frames

### Installation Instructions

Step 1:

Prepare Rough Opening (Special Dimensions)

Nominal Door

Size	Equation	A	R.O.
7'0"	Door + 4"		= 88"
8'0"	Door + 4"		= 100"

Step 2:

Slip back extension over the top of the basket back.  
Then screw into basket on both sides of back with  
#6 x 1" screws.

Step 3:

Slip split jamb extension on the top of the basket split jamb.  
Steel on top of basket will fit under 4" split jamb material.  
While aligning and butting wood together, screw directly into steel  
and wood from the back side with #6 x 2" screws.

Step 4:

Continue with Step 2 on pocket instructions.

